

Hook-Type Latches

**Stainless Steel, Operation with Socket Key,
Not Lockable**

SPECIFICATION

Types

- Type **DK**: With triangle
- Type **VK7**: With square
- Type **VK8**: With square
- Type **SCH**: With slot
- Type **VDE**: With double bit

Version of the hook

- **H1**: Pivoting radius $R=28$

Identification no.

- No. **1**: Without latch bracket
- No. **2**: With latch bracket

Lock housing

Stainless steel AISI 303 **N**

Other parts

Stainless steel AISI 304

Protection class IP 65

INFORMATION

Hook-type latches GN 115.8-WSK-NL-SST with hook and latch bracket are mainly used for sliding doors and flaps. The locking action is in radial direction to the axis of rotation, resulting in a wide variety of different uses.

The hook-type latches GN 115.8-WSK-NL-SST are supplied with loosely enclosed hook.

ACCESSORY






- GN 119.2 Socket Keys (see page 1530)
- GN 120 Protective Caps (see page 1486)
- GN 120.1 Opening Handles (see page 1487)

ON REQUEST

- Hook-type latches with other hook distance A
- Hook with other pivoting radius R

TECHNICAL INFORMATION

- Construction and assembly instructions (see page)
- Overview Latch Types (see page 1456)
- IP Protection Classes (see page A23)
- Stainless Steel Characteristics (see page A26)



GN 115.8-WSK-NL-SST-DK

STAINLESS STEEL

Description	Hook distance A	d	h	
GN 115.8-DK-18-H1-N-1	18	28	4	110
GN 115.8-DK-18-H1-N-2	18	28	4	155

GN 115.8-WSK-NL-SST-VK7

STAINLESS STEEL

Description	Hook distance A	d	h	
GN 115.8-VK7-18-H1-N-1	18	28	4	105
GN 115.8-VK7-18-H1-N-2	18	28	4	150

GN 115.8-WSK-NL-SST-SCH

STAINLESS STEEL

Description	Hook distance A	d	h	
GN 115.8-SCH-18-H1-N-1	18	28	4	182
GN 115.8-SCH-18-H1-N-2	18	28	4	227

GN 115.8-WSK-NL-SST-VK8

STAINLESS STEEL

Description	Hook distance A	d	h	
GN 115.8-VK8-18-H1-N-1	18	28	4	113
GN 115.8-VK8-18-H1-N-2	18	28	4	158

GN 115.8-WSK-NL-SST-VDE


STAINLESS STEEL

Description	Hook distance A	d	h	
GN 115.8-VDE-18-H1-N-1	18	28	4	103
GN 115.8-VDE-18-H1-N-2	18	28	4	149


* Dimensions of the latch bracket

* Dimensions of the latch bracket


Installation hole for punching or laser machining




Installation hole for drilling or milling



Assembly latch and hook



Dimensions of the latch bracket



Construction and assembly instructions

For installation, set a hole in the door, cover or hatch as shown in the outline drawing.

The required installation bore in the door leaf, is usually generated by punching or laser machining in series production.

The installation bore diameter can also be created by drilling or milling as shown in the outline drawings.

For small series and steel sheets below 2 mm thickness, the sheet metal punch GN 123 (see page 1493) are the tool of choice.

The hook can only be attached to the latch after installing the lock housing in the door leaf.

The bolt of the latch bracket can be shifted vertically within a slot by ± 5 mm, making it easier to adjust the latch during installation.

Ideally, the bolt should be in the plane of the rotational axis when locked, as shown. A sideways offset of as much as 4 mm does not impair the proper function.

The angle of rotation of the hook is normally limited to 90°.

Depending on the mounting of the contact pin supplied loose, the locking action is effected by turning left or right.

Without the contact pin, the hook can be rotated by 360°.